

# INSTALLATION AND OPERATING INSTRUCTIONS



## Touch sensor - dual-function version(010B)



### Technical details:


Supply voltage:		12V DC		
Transmitter:		12V 1A (max)		
Temperature range:		-20 to + 50 degrees Celsius		
Config.	Time of pressing the sensor	Sensor signal	Handle's reaction	Examples of using
010B	1sec, no longer than 3sec	- after finger recognition the sensor turns off - after removing finger sensor blinking for 3sec	on the control cable (green) remains positive potential for 3sec	control of electric catch or electric lock
	6sec	- after finger recognition the sensor turns off, and after 6sec it starts blinking until to remove finger	on / off inside transmitter	control of LED points in the handle

### Color of wires:




**!!WARNING!!**  
Installation should be done by qualified electrotechnician

### Electric catch



### Electric lock



### Mechanical bell

